

HTC													
	Touch	Touch	OK	OK	OK	OK	OK	OK	OK	OK	OK	X	OK
	P3470	P3470	OK	OK	OK	OK	OK	OK	OK	OK	OK	X	OK
	Touch-Dual	Touch-Dual	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
	NEXUS ONE	NEXUS ONE	OK	OK	OK	OK	OK	OK	X	X	OK	X	OK
	Legend	Legend	OK	OK	OK	OK	OK	OK	OK	OK	OK	X	OK
	Wildfire	Wildfire	OK	OK	OK	OK	OK	OK	OK	OK	OK	X	OK
	Tattoo	Tattoo	OK	OK	OK	OK	OK	OK	OK	OK	OK	X	OK
	F3188	F3188	OK	OK	OK	OK	OK	OK	OK	OK	OK	X	OK
	Desire HD (G10)	Desire HD	OK	OK	OK	OK	OK	OK	OK	OK	OK	X	OK
	S710e (G11)	S710e	OK	OK	OK	OK	OK	OK	OK	OK	OK	X	OK
	c110e	c110e	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
	Desire HD (G10)	Desire HD	OK	OK	OK	OK	OK	OK	OK	OK	OK	X	OK
	Sensation XE (G12)	Sensation XE	OK	OK	OK	OK	OK	OK	OK	OK	OK	X	OK
	ONE X (S720e)	ONE X	OK	OK	OK	OK	OK	OK	OK	OK	OK	X	OK
	Desire C (A320E)	Desire C	OK	OK	OK	OK	OK	OK	OK	OK	OK	X	OK
	J Z321e	J Z321e	OK	OK	OK	OK	OK	OK	OK	OK	OK	X	OK
	ONE SV	ONE SV	OK	OK	OK	OK	OK	OK	OK	OK	OK	X	OK
	Butterfly (X920e)	Butterfly	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
	NEW One (801e/802e)	One 801e	OK	OK	OK	OK	OK	OK	OK	OK	OK	X	OK
	Desire 600	Desire 600	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
	Z560e (One S)	Z560e (One S)	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
Huawei													
	Ideos	Ideos	OK	OK	OK	OK	OK	OK	OK	OK	OK	X	OK
	IDEOS U8510	IDEOS U8510	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
	MT1-U06	Z560e (One S)	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
I-mate													
	JAM	JAM	OK	OK	OK	OK	OK	OK	OK	OK	OK	X	OK
	PDA2K	PDA2K	OK	OK	OK	OK	OK	OK	OK	OK	OK	X	OK
	SP3	SP3	OK	OK	OK	OK	OK	OK	OK	OK	OK	X	OK
	Pocket PC	Pocket PC	OK	OK	OK	OK	OK	OK	OK	OK	OK	X	OK
kejian													

