藍芽系統適用之手機與功能一覽表

<u>監牙系統週用</u> ~	乙于機與功能一覽表						
手機廠牌	手機型號	自動接聽	CallerId	末碼重	結束	聲控/搖控	支援手機型號*6
Version:4317		來電	播報	撥功能	通話	撥號(方向	
			(來電顯			盤按鍵控	
			示)			制功能)	
AMOi							
	N5000	OK	OK	OK	OK	OK	N5000
	A1	OK	OK	OK	OK	OK	A1
Apple							
	iPhone(3G)	OK	X	OK	OK	OK	iPhone(3G)
	iPhone(3G)	OK	X	OK	OK	OK	iPhone(3G)
	iPhone(3GS)	OK	X	OK	OK	OK	iPhone(3GS)
	iPhone 4	OK	OK	OK	OK	OK	iPhone 4
	iPhone 4s	OK	OK	OK	OK	OK	iPhone 4s
	iPhone 5	OK	OK	OK	OK	OK	iPhone 5
2013/12/30	iPhone 5s	OK	OK	OK	OK	OK	iPhone 5s
ASUS							
	V70	OK	OK	OK	OK	OK	V70
	Ik03	OK	X	OK	OK	OK	Ik03
	V80	OK	X	OK	OK	OK	V80
	P320	X	X	X	X	X	P320*9
ACER							
	stream	OK	OK	OK	OK	X	stream
	liquid	OK	OK	OK	OK	X	liquid
BENO-SIEM	ENS						
	S55	OK	OK	OK	OK	OK	S55, S56 *3
	S65	OK	OK	OK	OK	OK	S65 *3
	CL71	OK	X	OK	OK	OK	CL71
	EF91	OK	OK	OK	OK	OK	EF91
	T51	OK	OK	OK	OK	OK	T51
·		•	•				•

手機廠牌	手機型號	自動接聽	CallerId	末碼重	結束	聲控/搖控	支援手機型號*6
Version:4317		來電	播報	撥功能	通話	撥號(方向	
			(來電顯			盤按鍵控	
			示)			制功能)	
	M7	OK	OK	OK	OK	OK	M7*7
	E72	X	X	X	X	X	
	T60	OK	OK	OK	OK	OK	T60*8
Black Berry (黑莓機)						
	8300	OK	OK	OK	OK	OK	8300
	8120	OK	OK	OK	OK	OK	8120
	9500 Storm	OK	OK	OK	OK	OK	9500 Storm
	8820	OK	OK	X	OK	OK	8820
	9700	OK	OK	OK	OK	OK	9700
	9000	OK	OK	OK	OK	OK	9000
	9105	OK	OK	OK	OK	OK	9105
	8900	OK	OK	OK	OK	OK	8900
	9860	OK	OK	OK	OK	OK	9860
	Z10	OK	OK	OK	OK	OK	Z10
	8520	OK	OK	OK	OK	OK	8520
CHT							
	3000	OK	OK	OK	OK	OK	3000
	9100	X	X	X	X	X	9100*9
	5000	OK	OK	OK	OK	OK	
HP							
	rw6816	OK	OK	OK	OK	OK	rw6816
HTC							
	LEgend	OK	OK	OK	OK	X	Legend
	Wildfire	OK	OK	OK	OK	X	Wildfire
	Tattoo	OK	OK	OK	OK	X	Tattoo
	F3188	OK	OK	OK	OK	X	F3188

手機廠牌	手機型號	自動接聽	CallerId	末碼重	結束	聲控/搖控	支援手機型號*6
Version :4317	J ////	來電	播報			撥號(方向	
		71	(來電顯	10% - > 2 1/1 []	مراجع	盤按鍵控	
			示)			制功能)	
			7117			いいろいはログ	
	Desire HD (G10)	OK	OK	OK	OK	X	Desire HD
	S710e (G11)	OK	OK	OK	OK	X	S710e
	c110e	OK	OK	OK	OK	OK	c110e
	Desire HD (G10)	OK	OK	OK	OK	X	Desire HD
	Sensation À⊏ (C19)	OK	OK	OK	OK	X	Sensation XE
	ONE X (S720e)	OK	OK	OK	OK	X	ONE X
	Desire C (A320E)	OK	OK	OK	OK	X	Desire C
	J Z321e	OK	OK	OK	OK	X	J Z321e
	ONE SV	OK	OK	OK	OK	X	ONE SV
	Butterfly (X920e)	OK	OK	OK	OK	OK	Butterfly
	NEW One (801e/802e)	OK	OK	OK	ОК	X	One 801e
	Desire 600	OK	OK	OK	OK	OK	Desire 600
	Z560e(One S)	OK	OK	OK	OK	OK	Z560e(One S)
Huawei							
	Ideos	OK	OK	OK	OK	X	Ideos
	IDEOS U8510	OK	OK	OK	OK	OK	IDEOS U8510
	MT1-U06	OK	OK	OK	OK	OK	MT1-U06
Google							
	Nexus One	X	X	X	X	X	Nexus One
T (/ D							
I-mate / Dopo		0.17	0.17	0.17	0.17	0.77	
	700	OK	OK	OK	OK	OK	PDA2K*7
	699	OK	OK	OK	OK	OK	Pocket PC*7
	NEXUS ONE	OK	OK	OK	OK	OK	
LG							
	KG800	OK	OK	OK	OK	OK	KG800
	C3380	OK	X2	OK	OK	OK	C3380
	G262	OK	X	OK	OK	OK	G262

手機廠牌 Version :4317	手機型號	自動接聽 來電	CallerId 播報 (來電顯 示)	末碼重 撥功能	結束通話	聲控/搖控 撥號(方向 盤按鍵控 制功能)	支援手機型號*6
	KU800	OK	OK	OK	OK	OK	KU800
	KE590/KE590 I- mode/KE500	ОК	OK	OK	OK	ОК	KE590
	KE970/KE970c/KE 970d/KG70	OK	OK	OK	OK	OK	KE970
	KF510	OK	OK	OK	OK	OK	KF510
	KM501	OK	OK	OK	OK	OK	KM501
	KU250	OK	OK	OK	OK	OK	KU250
	KU990	OK	OK	OK	OK	OK	KU990
	KM380/KM380c/K M380T/KM385d/K M386c	OK	OK	OK	ОК	OK	KM380
	KE770	OK	OK	OK	OK	OK	KE770
	KF350	OK	OK	OK	OK	OK	KF350
	KE800	OK	OK	X	OK	OK	KE800
	KE820	OK	OK	X	OK	OK	KE820
	KM900	OK	OK	X	OK	OK	KM900
	E720	X	X	X	X	X	E720
	T515	OK	OK	OK	OK	X	T515
	P970	OK	OK	OK	OK	X	P970
	P705	OK	OK	OK	OK	X	P705
	E400	OK	OK	OK	OK	X	E400
	E975	OK	OK	OK	OK	X	E975
2013/12/30	Nexus 5	OK	OK	OK	OK	OK	Nexus 5
Mio							
	A700	X	X	X	X	X	A700
D/I a 4 a see la							
Motorola	1 = <0	077	***	077	077		
	A760	OK	X1	OK	OK	X1	A760, A768, A760i, A768i

手機廠牌	手機型號		CallerId				支援手機型號*6
Version :4317		來電	播報	撥功能	通話	撥號(方向	
			(來電顯			盤按鍵控	
			示)			制功能)	
	11 COO /1100						11500 11500 11505 1100
	V600/V80	OII	OII	OII	017	OII	V600,V500,V525, V80,
		OK	OK	OK	OK	OK	E398, A630, E550, V535,
	***	0.17	0.17	0.77	0.17	077	V545, V550, V600i, V620
	V3	OK	OK	OK	OK	OK	V3
	E398	OK	OK	OK	OK	OK	E398
	E680i/E680	OK	OK	OK	OK	OK	E680i
	E1000	OK	OK	OK	OK	OK	E1000
	V360	OK	OK	OK	OK	OK	V360
	A732	OK	OK	OK	OK	OK	A732*2
	V3i	OK	OK	OK	OK	OK	V3i
	E770	OK	OK	OK	OK	OK	E770
	L6	OK	OK	OK	OK	OK	L6
	PBEL U6	OK	OK	OK	OK	OK	PBEL U6
	V361	OK	OK	OK	OK	OK	V361
	V501	OK	NA	OK	OK	OK	V501
	明	X	X	X	X	X	明
	E6	OK	NA	OK	OK	OK	E6
	KRZR K1	OK	NA	OK	OK	OK	KRZR K1
	Z3	OK	OK	OK	OK	OK	Z3
	W510	OK	OK	OK	OK	OK	W510
	V8	X	X	X	X	X	V8
	SLVR	OK	OK	OK	OK	OK	L72
	RAZR maxx						
	V1100/V3xx/V6	OK	OK	OK	OK	OK	V1100
	maxx V3	OK	OK	OK	OK	OK	V3
	E8/U9/EM30	X	X	X	X	X	E8
	Q9H	OK	X	OK	OK	X	Q9H
	V9/Z9/V3xxR/V9x	OK	OK	OK	OK	OK	V9
	ZN200	OK	OK	OK	OK	OK	ZN200
	A810	OK	Χ	OK	OK	OK	A810

手機廠牌 Version :4317	手機型號	自動接聽 來電	CallerId 播報	末碼重 撥功能	結束 通話	聲控/搖控 撥號(方向	支援手機型號*6
			(來電顯			盤按鍵控	
			示)			制功能)	
	ZN5	0.77	0.77	0.77	0.77	0.77	ZN5
	V3x	OK	OK	OK	OK	OK	V3x
	U9	OK	OK	OK	OK	OK	U9*7
	A1800	OK	OK	OK	OK	OK	A1800
	ME860	OK	OK	OK	OK	OK	ME860
	MB525	OK	OK	OK	OK	OK	MB525
	XT615	X	X	X	X	X	XT615
NEC							
	N840	X	X	X	X	X	N840
	N500is	X	X	X	X	X	N500is
NOKIA							
	7610	OK	OK	OK	OK	OK	7610 *2
	7600	OK	OK	OK	OK	OK	7600 *2
	6230	OK	OK	OK	OK	OK	6230 *2
	6820	OK	OK	OK	OK	OK	6820 *2
	6600	OK	X2	OK	OK	OK	6600
	8910i	OK	OK	OK	OK	OK	8910i
	3650	OK	X2	OK	OK	OK	3650, 3660 *4
	8910	OK	OK	OK	OK	OK	8910
	6310i	OK	OK	OK	OK	OK	6310i
	6310	OK	OK	OK	OK	OK	6310
	6260	OK	OK	OK	OK	OK	6260 *2
	7280	OK	OK	OK	OK	OK	7280 *2
	6680	OK	OK	OK	OK	OK	6680
	6230i	OK	OK	OK	OK	OK	6230i
	6670	OK	OK	OK	OK	OK	6670 *2
	N70	OK	OK	OK	OK	OK	N70
	6111	OK	OK	OK	OK	OK	6111
	6270	OK	OK	OK	OK	OK	6270

手機廠牌	手機型號	自動接聽	CallerId	末碼重	結束	聲控/搖控	支援手機型號*6
Version:4317		來電	播報	撥功能	通話	撥號(方向	
			(來電顯			盤按鍵控	
			示)			制功能)	
	7370	OK	OK	OK	OK	OK	7370
	6103	OK	OK	OK	OK	OK	6103
	6131	OK	OK	OK	OK	OK	6131
	6280	OK	OK	OK	OK	OK	6280
	3250	X	X	X	X	X	3250
	N73	OK	NA	OK	OK	OK	N73
	6151/6233/6234	OK	OK	OK	OK	OK	6151
	6288	OK	NA	OK	OK	OK	6288
	5200	OK	OK	OK	OK	X	5200
	6233	OK	OK	OK	OK	OK	6233
	7390	OK	OK	OK	OK	OK	7390
	E70	OK	OK	OK	OK	OK	E70
	6085	OK	OK	OK	OK	OK	3085
	5200	OK	OK	OK	OK	OK	5200
	N91	OK	OK	OK	OK	OK	N91
	E61	OK	OK	OK	OK	OK	E61
	3110	OK	OK	OK	OK	OK	3110
	E65	OK	OK	OK	OK	OK	E65
	5310	OK	X	OK	OK	OK	5310
	6500C	OK	OK	OK	OK	OK	6500C
	N70(New)	OK	OK	OK	OK	OK	N70
	5700	OK	OK	OK	OK	OK	5700*7
	5300	OK	OK	OK	OK	OK	5300
	N73	OK	OK	OK	OK	OK	N73
	3600s	OK	OK	OK	OK	OK	3600s
	6210 Navigator	OK	OK	OK	OK	OK	6210 Navigator
	2600c	OK	OK	OK	OK	OK	2600c
	2630	OK	OK	OK	OK	OK	2630
	2660	OK	OK	OK	OK	OK	2660
	2760	OK	OK	OK	OK	OK	2760

手機廠牌	手機型號	自動接聽	CallerId	末碼重	結束	聲控/搖控	支援手機型號*6
Version :4317		來電	播報	撥功能	通話	撥號(方向	
			(來電顯			盤按鍵控	
			示)			制功能)	
	6267	OK	OK	OK	OK	OK	6267
	6555	OK	OK	OK	OK	OK	6555
	7500 Prism	OK	OK	OK	OK	OK	7500 Prism
	3610 fold	OK	OK	OK	OK	OK	3610 fold
	6121	OK	OK	OK	OK	OK	6121*7
	E51	OK	OK	OK	OK	OK	E51*7
	E66	OK	OK	OK	OK	OK	E66*7
	E71	OK	OK	OK	OK	OK	E71*7
	N82	OK	OK	OK	OK	OK	N82*7
	6124	OK	OK	OK	OK	OK	6124*7
	5220	OK	OK	OK	OK	OK	5220
	7610S	OK	OK	OK	OK	OK	7610S
	7210C	OK	OK	OK	OK	OK	7210C
	2680	OK	OK	OK	OK	OK	2680
	5000	OK	OK	OK	OK	OK	5000
	5130	OK	OK	OK	OK	OK	5130
	6208	OK	OK	OK	OK	OK	6208
	7100	OK	OK	OK	OK	OK	7100
	7212C	OK	OK	OK	OK	OK	7212C
	6202C	OK	OK	OK	OK	OK	6202C
	6208C	OK	OK	OK	OK	OK	6208C
	2700C	OK	OK	OK	OK	OK	2700C
	7310C	OK	OK	OK	OK	OK	7310C
	6210S	OK	OK	OK	OK	OK	6210S
	6290	OK	OK	OK	OK	OK	6290
	2330C	OK	OK	OK	OK	OK	2700C
	6208C	OK	OK	OK	OK	OK	6208C
	N96	OK	OK	X	OK	OK	N96
	6500S	OK	OK	OK	OK	OK	6500S
	5610	OK	OK	OK	OK	OK	5610

手機廠牌	手機型號		CallerId				支援手機型號*6
Version :4317		來電		撥功能	通話	撥號(方向	
			(來電顯			盤按鍵控	
			示)			制功能)	
	5132	OK	OK	OK	OK	OK	5132
	2332c	OK	OK	OK	OK	OK	2332c
	3208c	OK	OK	OK	OK	OK	3208c
	2323c	OK	OK	OK	OK	OK	2323c
	6300i	OK	OK	OK	OK	OK	6300i
	6290	OK	OK	OK	OK	OK	6290
	7900	OK	OK	OK	OK	OK	7900
	N93i	OK	OK	OK	OK	OK	N93i
	E70	OK	OK	OK	OK	OK	E70
	C5-00	OK	OK	OK	OK	OK	C5-00
	6700S	OK	OK	OK	OK	OK	6700S
	5230	OK	OK	OK	OK	OK	5230
	X3-00	OK	OK	OK	OK	OK	X3-00
	3710 fold	OK	OK	OK	OK	OK	3710 fold
	c7	OK	OK	OK	OK	OK	c7
	X3-02	OK	OK	OK	OK	X	X3-02
	N8	OK	OK	OK	OK	OK	N8
	7230	OK	OK	OK	OK	OK	7230
	5230	OK	OK	OK	OK	OK	5230
	C6-00	OK	OK	OK	OK	OK	C6-00
	N97	OK	OK	OK	OK	OK	N97
	Asha 311	OK	OK	OK	OK	OK	Asha 311
	Lumia 620	OK	OK	OK	OK	OK	Lumia 620
O2							
	Zine	X	X	X	X	X	Zine
	Atom Life	X	X	X	X	X	xda Atom Life
	Xda Zinc	X	X	X	X	X	Xda Zinc
OKWAP							

手機廠牌	手機型號		CallerId				支援手機型號*6
Version:4317		來電	播報	撥功能	通話	撥號(方向	
			(來電顯			盤按鍵控	
			示)			制功能)	
	i900	OK	X	OK	OK	OK	i900
	S868	X	X	X	X	X	S868
Panasonic							
	X70	OK	OK	OK	OK	OK	X70, X88 *3
	X700	OK	OK	OK	OK	OK	X700/X701
	X800	OK	OK	OK	OK	OK	X800
	VS7	OK	OK	OK	OK	OK	VS7
PANTECH							
	PG-3600v	X	X	X	X	X	PG-3600v
Plam							
	Treo 680	X	X	X	X	X	Treo 680
PHS							
	PG930	OK	OK	OK	OK	OK	PG930
Sagem							
	My X-6	OK	OK	OK	OK	OK	My X-6
	My510x	OK	X	OK	OK	OK	My510x
	My700xi	OK	X	OK	OK	OK	My700xi
Samsung							
	SGH-	OK	ОК	OK	OK	OK	
	E738/E730/E736	UK	UK	UK		OK	SGH-E738/E730/E736
	SGH-	OK	ОК	OK	OK	OK	
	D500/508/500C/500	UK	UK	UK	UK	OK	SGH-D500/508/500C/500E
	SGH-E568	OK	OK	OK	OK	OK	SGH-E568

手機廠牌	手機型號	自動接聽	CallerId		結束	7	
Version :4317		來電		撥功能	通話	撥號(方向	
			(來電顯			盤按鍵控	
			示)			制功能)	
	SGH-D608	OK	OK	OK	OK	OK	SGH-D608
	SGH-D528	OK	OK	OK	OK	OK	SGH-D528
	SGH-E908/D900	OK	OK	OK	OK	OK	E908
	SGH-D508	OK	OK	OK	OK	OK	D508
	SGH-P858	OK	OK	OK	OK	OK	SGH-P858
	SGH-D838	OK	OK	OK	OK	OK	SGH-D838
	SGH-Z238	OK	NA	OK	OK	OK	SGH-Z238
	SGH-E908	OK	NA	OK	OK	OK	SGH-E908
	SGH-E378	OK	NA	OK	OK	OK	SGH-E908
	SGH-Z248	OK	OK	OK	OK	OK	SGH-Z248
	SGH-	OK	OK	OK	OK	OK	
	L768/L760/L760V	OK	OK	OK	UK	OK	SGH-L768
	SGH-J208/J200	OK	OK	OK	OK	OK	SGH-J208*7
	SGH-i548B	OK	OK	OK	OK	OK	SGH-i548B
	SGH-J408	OK	X	OK	OK	OK	SGH-J408
	SCH-F609	X	X	X	X	X	SCH-F609
	SGH-F268	X	X	X	X	X	SGH-F268*9
	SGH-i608	X	X	X	X	X	SGH-i608*a
	SGH-U808	OK	OK	OK	OK	OK	SGH-U808
	SGH-F258	OK	OK	OK	OK	OK	SGH-F258
	SGH-U908	OK	OK	OK	OK	OK	SGH-U908*7
	SGH-i908	X	X	X	X	X	SGH-i908
	GT-5650U	OK	OK	OK	OK	OK	GT-5650U
	GT-I5801	OK	OK	OK	OK	X	GT-I5801
	R(i9103)	OK	OK	OK	OK	X	GT-I9003
	F480T	OK	OK	OK	OK	X	F480T
	SGH F258	OK	OK	OK	OK	X	SGH F258
	Corby S3650	OK	OK	OK	OK	X	Corby S3650
	i9103	OK	OK	OK	OK	OK	i9103
	S5380D	OK	OK	OK	OK	X	S5380D

手機廠牌	手機型號	自動接聽	CallerId	末碼重	結束	聲控/搖控	支援手機型號*6
Version :4317		來電		撥功能		撥號(方向	
		. –	(來電顯			盤按鍵控	
			示)			制功能)	
			71.9			(D14/27)	
	GT-I9250	OK	OK	OK	OK	OK	GT-I9250
	GT-I9100	OK	OK	OK	OK	OK	GT-I9100
	E2652W	OK	OK	OK	OK	X	E2652W
	Ualaxy	OK	OK	OK	OK	OK	Galaxy Note
	GT-I9300	OK	OK	OK	OK	OK	GT-I9300
	S7500	OK	OK	OK	OK	X	S7500
	N7100	OK	OK	OK	OK	OK	N7100
	S3 mini(i8190)	OK	OK	OK	OK	OK	S3 mini
	S4(i9500)	OK	OK	OK	OK	OK	S4
	GT-I9200	OK	OK	OK	OK	OK	GT-I9200
	Note 3	OK	OK	OK	OK	OK	Note 3
SHARP							
	GX-15	OK	OK	OK	OK	OK	GX-15
	GX-31	OK	OK	OK	OK	OK	GX-31
	T91	OK	OK	OK	OK	OK	T91
	T17	OK	NA	OK	OK	OK	T17
	WX-T81	OK	OK	OK	OK	OK	WX-T81*7
	GX-T33	X	X	X	X	X	GX-T33*7
	SH930W	OK	OK	OK	OK	OK	SH930W
SonyEricsson	1						
	K700i/K700c	X	X	X	X	X	K700i/K700c
	Z600	OK	OK	OK	OK	OK	Z600, Z608
	T610/T630	OK	OK	OK	OK	OK	T610, T618, T628, T630
	P800	OK	X1	OK	OK	X1	P80x *1
	T68i(R6A,R8A)	OK	OK	OK	OK	OK	T68i *1
	T68i(R2A)	OK	OK	OK	OK	OK	T68i *1
	T68	OK	OK	OK	OK	OK	T68 *1
	S700/S700i/S710a	OK	OK	OK	OK	OK	S700/S700i/S710a

手機廠牌	手機型號	自動接聽	CallerId	末碼重	結束	聲控/搖控	支援手機型號*6
Version:4317		來電	播報	撥功能	通話	撥號(方向	
			(來電顯			盤按鍵控	
			示)			制功能)	
			. /			1 4 7 3 7 4 2 7	
	P900	OK	OK	OK	OK	OK	P900
	W550i	OK	OK	OK	OK	OK	W550i
	Z520i	OK	OK	OK	OK	OK	Z520i
	K800i/K800xx	X	X	X	X	X	K800i/K800xx
	K750i/K750c/K750	X	X	X	X	X	K750i/K750c/K750
	D750	X	X	X	X	X	D750
	W800c/W800/W70	X	X	X	X	X	W800c/W800/W700
	Z800i/Z800c	X	X	X	X	X	Z800i/Z800c
	Z550i	OK	OK	OK	OK	OK	Z550i
	W710i	OK	OK	OK	OK	OK	W710i
	W850i	OK	OK	OK	OK	OK	W850i
	Z610i	OK	OK	OK	OK	OK	Z610i
	Z710i/Z712a/Z710x	OK	OK	OK	OK	OK	Z710i/Z712a/Z710x
	K510i	OK	OK	OK	OK	OK	K510i
	K810i	OK	OK	OK	OK	OK	K810i
	W700i/W700c	X	X	X	X	X	W700i/W700c
	W850i/W850xx	OK	OK	OK	OK	OK	W850i/W850xx
	K550i/K550c/K550i	OK	OK	OK	OK	OK	K550im
	K610i/K610im/K61 0xx	OK	OK	OK	OK	OK	K610i/K610im/K610xx
	K608i	OK	OK	OK	OK	OK	K608i
	W660i	OK	OK	OK	OK	OK	W660i
	K850i/K850a/K858	OK	OK	OK	OK	OK	K850i
	K530i	OK	OK	OK	OK	OK	K530i
	Pli	OK	OK	OK	OK	OK	Pli
	M600i	X	X	X	X	X	M600i
	K660i	OK	OK	OK	OK	OK	K660i
	W910i	OK	OK	OK	OK	OK	W910i
	Z555	OK	OK	OK	OK	OK	Z555
	W380i	OK	OK	OK	OK	OK	W380i

手機廠牌	手機型號	自動接聽	CallerId	末碼重	結束	聲控/搖控	支援手機型號*6
Version:4317		來電	播報	撥功能	通話	撥號(方向	
			(來電顯			盤按鍵控	
			示)			制功能)	
	T303	OK	OK	OK	OK	OK	T303
	R306	OK	OK	OK	OK	OK	R306
	G700	OK	OK	OK	OK	OK	G700
	G502	OK	OK	OK	OK	OK	G502
	C902	OK	OK	OK	OK	OK	C902
	C702	OK	OK	OK	OK	OK	C702
	T700	OK	OK	OK	OK	OK	T700
	T707	OK	OK	OK	OK	OK	T707*7
	W980	OK	OK	OK	OK	OK	W980
	Z750i/Z750a	OK	OK	OK	OK	OK	Z750i/Z750a
	W902	OK	OK	OK	OK	OK	W902
	W595	OK	OK	OK	OK	OK	W595
	W395	OK	OK	OK	OK	OK	W395
	J10i2	OK	OK	OK	OK	OK	J10i2
	Xperia X8	OK	OK	OK	OK	X	Xperia X8
	Xperia Neo	OK	OK	OK	OK	OK	Xperia Neo
	Xperia Ray	OK	OK	OK	OK	OK	Xperia Ray
	K810i	OK	OK	OK	OK	X	K810i
	Xperia S	OK	OK	OK	OK	OK	Xperia S
	MT27i	OK	OK	OK	OK	OK	MT27i
	Xperia Z	OK	OK	OK	OK	OK	Xperia Z
	Xperia L	OK	OK	OK	OK	OK	Xperia L
SOWA							
	D258-Plus	OK	OK	OK	OK	X	D258-Plus
Taiwan Mob	ile						
	T2	OK	OK	OK	OK	X	T2
TOSHIBA							
	TS32	OK	X	OK	OK	OK	TS32
	G810	X	X	X	X	X	G810*a

手機廠牌	手機型號	自動接聽	CallerId	末碼重	結束	聲控/搖控	支援手機型號*6
Version:4317			播報			撥號(方向	
			(來電顯			盤按鍵控	
			示)			制功能)	
vodafone							
	1210	OK	OK	OK	OK	OK	1210
Viewsonic							
	VPAD7	OK	OK	OK	OK	OK	VPAD7
Wmbile							
	GC909	X	X	X	X	X	GC909
ZIKOM							
	Z-950	OK	OK	OK	OK	X	Z-950
Xiaomi							
	小米機2S	OK	OK	OK	OK	OK	小米機2S

備註:

- *1:手機端藍芽設定須設定為進階模式,才可使用方向盤Switch或遙控撥號功能.
- *2: Nokia7600/7610/6820/6230/6260 使用東信/台灣大哥大 SIM卡,通話結束時由發話方掛話

手機廠牌 Version :4317	手機型號	自動接聽 來電			聲控/搖控 撥號(方向	支援手機型號*6
			(來電顯 示)		盤按鍵控制功能)	

- ,音響沒有回復,Moto A732使用中華電信SIM卡亦會有此問題. (此乃手機端系統與電信業者溝通問題). 必須由手機或搖控器或方向盤控制器掛話,音響才會正常回復.
- *3: Call out 時,聲音預設在手機端,必須由手機端操作,聲音才會轉至免持聽筒端, 此乃手機端系統設計緣故.
- *4:手機當機率高.
- *5:若可支援之藍芽手機功能與上述公布內容不符之問題, 請洽怡利客服專線:0800079889
- *6:BQB認証為藍芽SIG協會對藍芽產品的相容性認証, 同一系列廠牌之手機通過認証代表其藍芽功能相容.
- *7:通話時無法調整音量大小
- *8: Call in 時,喇叭無來電鈴聲,接通後ok
- *9: 配對完後,無法連線
- *a: 配對時找不到device

X:完全不支援.

X1:本手機僅支援Headset-AG profile, 無此功能.

X2: 手機傳送空白或錯誤 CallerId.

更新日期:2013/12/30

偶發狀況無法轉藍芽免持功能,此乃手機問題,測試原廠 Car Kit 亦有同樣情形.